

Benefon Developer License

SW1700

Preliminary data sheet

Benefon Developer License is a for everyone who wants to use MPTP protocol or other Benefon documentation with detailed information on Benefon products in order to create their own solution.

Benefon Developer License allows access for documentation on protocols and commands that are compatible with all the Benefon products. You will be given a personal login and password to access the Benefon developer zone in the Benefon website after you have purchased the licence and registered as a partner. A set of protocol documents including MPTP and AT commands among others with clear examples and example programming codes are downloadable from this site. You will also receive the best technical support for your assistance in using these protocols

What Benefon Developer License Offers

Benefon Developer Licence offers access to the Benefon Developer Zone. Benefon Developer Zone is an area where you will receive the most detailed information on our mobile telematics instruments. After purchasing a licence you will get one year's access to this area and you can renew your license annually. A bulletin alerting you to updates in the documentation on the website will be sent to you as soon as the updates are available to your defined email address.

Documents are updated at the same time as our devices so that the latest information is always available as soon as the new product is launched.

Benefon Developer Zone

- Mobile Phone Telematic Protocol (MPTP) documentation to control and configure all Benefon telematic instruments.
- AT-commands specification of supported GSM commands are listed in clear document along with full description of Benefon proprietary commands that allow local configuration and control.
- Benefon Software Development Kit (SDK).
- Over the air (OTA) for Web/WAP/E-mail settings.
- Device Driver files.
- Specification documents on various extra features.
- Trace download binary to text.
- Encryption module.
- Encryption key maker.
- Supported NMEA commands.

More information in www.benefon.com